

UltraLight Magnetic Loop Antenna MC-20, also for Ver.4

Thank you for purchasing my QRP portable Magnetic Loop Antenna!

How to operate with this antenna:

1. Assemble the antenna by the video instruction on my YT channel or scan this QR code ----->> <https://youtu.be/tyo04-DISws>
2. Connect the antenna feedline to the transceiver and tune it to a desired band and frequency.
2. Rotate the knob on the bottom side of the tuning box until you will hear a noise peak in TRX.
3. Switch your TRX in to some carrier mode (FM, AM, RTTY – 5/10W) and TX - now find with knob the best SWR value. Internal or external SWR meter is required.
4. Your antenna is ready to work.
5. After change your working frequency you have to use the tuning knob to re-tune your antenna with TX in the carrier mode again.



My website: <http://www.sk-tech.sk/om0et/index.html>



My YouTube channel: <https://www.youtube.com/c/OMOET>



Our QRP facebook group: <https://www.facebook.com/groups/2070036729808567/>

